

APPLIANCE AND LIGHTING



Hybrid Electric Water Heater

Test System Assembly Specification

Rev. 2

JOHN CONWAY

5/19/2011



Revision History

| Revision | Date | Notes |
|----------|-----------|--|
| 0 | 9/1/2010 | Original |
| 1 | 9/7/2010 | Updated Channel Config Chart, Added Items 44,45 to TCB BOM, Updated Schematics, added p4 to schematics, Revision Section |
| 2 | 5/19/2011 | Updated drawings, bom, for 2011. |



Contents

| | |
|---|----|
| <i>Revision History</i> | 2 |
| <i>Contents</i> | 3 |
| <i>List of Figures</i> | 4 |
| <i>List of Attachments</i> | 4 |
| 1. Overview | 5 |
| 2. Test Control Box (TCB) | 5 |
| 2.1. Equipment | 5 |
| 2.1.1. Yokogawa MW100 Configuration | 6 |
| 2.1.2. Channel Configuration | 6 |
| 2.2. Bill of Materials | 8 |
| 2.3. External Connections | 10 |
| 2.3.1 Terminals for External Sensors..... | 10 |
| 2.4. Power | 11 |
| 3. Patch Panel Box (PPB) | 11 |
| 3.1 Pin Outs..... | 12 |
| 3.2 Heater Relay Inputs..... | 12 |
| 3.3 Bill of Material..... | 13 |
| 4. Further Considerations | 13 |



List of Figures

| | |
|---|----|
| Figure 1 Channel Configuration | 7 |
| Figure 2 Bill of Material for the TCB | 9 |
| Figure 3 Terminal Block Wiring..... | 10 |
| Figure 4 Sensor Pin Out..... | 12 |
| Figure 5 Bill of Material for the PPB..... | 13 |

List of Attachments

| |
|---|
| Schematic HEWH-CB1 HEWH-Control Box Pages 1 – 5 |
| Drawing HEWHCB1 HEWH DAQ Box Page 1 of 1 |
| Drawing HEWHPP1 HEWH Patch Panel Page 1 of 1 |
| Drawing 4 Panel Connector 4 Pin |
| Drawing 5 Panel Connector 5 Pin |
| Drawing 6 Panel Connector 6 Pin |



1. Overview

The Hybrid Electric Water Heater (HEWH) will be tested according to the Department of Energy “APPENDIX E TO SUBPART B OF PART 430—UNIFORM TEST METHOD FOR MEASURING THE ENERGY CONSUMPTION OF WATER HEATERS.”

To comply with this test methodology, a test system shall be employed composed of several elements. A plumbing, water supply, electrical supply, and environmental control chambers shall be employed. A Test Control Box (TCB) shall be mounted on the outside of the environmental control chambers. The TCB shall contain the computer and data acquisition and control equipment to run the test. This box shall be wired to the control elements and sensors on the outside of the chamber, and also wired to a Patch Panel Box (PPB) mounted inside the environmental control chamber. The PPB will have the connectors that will go to the sensors on the Hybrid Electric Water Heater.

This document will describe the configuration of the Test Control Box, and the Patch Panel Box.

2. Test Control Box (TCB)

Note items are noted with curly brackets{*N*} The number *N* is noted in the Ref column of the BOM.

2.1. Equipment

The Test Control Box (TCB) shall have a fanless industrial computer{34} mounted to the door. This computer shall run a program to interface to a Yokogawa MW100 data acquisition system{11-17}, an Agilent 34972A{18,19}, and a USB to serial port converted{2}. These pieces of equipment shall be connected through an industrial Ethernet switch{1}.



2.1.1. Yokogawa MW100 Configuration

The Yokogawa MW100 will have a 6 slotted back plane. The cards shall be mounted in the following order:

| | |
|--------|--|
| Slot 0 | Analog output 8 Channel MX120-VAO-M08 |
| Slot 1 | Analog Input 10 Channel MX110-UNV-M10 |
| Slot 2 | Analog Input 10 Channel MX110-UNV-M10 |
| Slot 3 | Analog (RTD) Input 6 Channel MX110-V4R-M06 |
| Slot 4 | Discrete Output 10 Channel MX110-UNV-M10 |
| Slot 5 | Empty |

2.1.2. Channel Configuration

The channel connections shall be according to the following table.

| Channel | Description | Signal |
|-----------|-------------------------------|------------------|
| 001 | Flow Control Intellifacet | 4-20 MA |
| 011 | Pressure - High Side 1 | 1-5V |
| 012 | Pressure - High Side 2 | 1-5V |
| 013 | Pressure - Low Side | 1-5V |
| 014 | Pressure - Pinput | 1-5V |
| 015 | Current - 20A Top Heater | DI 240 VAC Relay |
| 016 | Current - 20A Bot Heater | DI 240 VAC Relay |
| 017 | Temp Shell 2-4 | Thermocouple - T |
| 018 | Flow | 0-10V |
| 019 | Watt Sense | 0-5V |
| 020 | Watt Tick | Contact |
| 021 - 026 | Temp Tank Tree | Thermocouple - T |
| 027 | Temp Downspout | Thermocouple - T |
| 028-030 | Temp Shell 2-4 | Thermocouple - T |
| 031 | Temp RTD Tin | 4 wire RTD |
| 032 | Temp RTD Tout | 4 wire RTD |
| 033 | Temp RTD Tamb | 4 wire RTD |
| 034 | Voltage | 0-10V |
| 041 | Temp/Flow DO to intellifaucet | Contact |
| 042 | Ready DO to intellifaucet | Contact |
| 043 | Start to intellifaucet | Contact |
| 044 | Stop to Intellifaucet | Contact |
| 045 | Pin 2 - DRM 1 (input Low Bit) | Contact |



| | | |
|-----------------|-------------------------------|-------------------|
| 046 | Pin 3- DRM 0 (input High Bit) | Contact |
| 047 | Water Heater Power | 240 VAC Contactor |
| 048 | Solenoid Purge | 120 VAC Relay |
| 049 | Solenoid Fill tank | 120 VAC Relay |
| 050 | Solenoid Tank Output | 120 VAC Relay |
| Agilent 101-104 | Temp Xtra (4) | Thermocouple - T |
| Agilent 105-109 | Temp Evaporator (5) | Thermocouple - T |
| Agilent 110-114 | Temp Dry/wet bulb (4) | Thermocouple - T |
| Agilent 201-205 | Temp Controls Trise (5) | Thermocouple - T |
| Agilent 206-211 | Temp shadow T1-T5 (6) | Thermocouple - T |
| Agilent 212-214 | Temp Tsuction, Tdis, Tret (3) | Thermocouple - T |
| Agilent 301-311 | Temp Tcondenser (12) | Thermocouple - T |

Figure 1 Channel Configuration

The analog signals shall be carried in individually shielded twisted pairs. An extra terminal connection will be provided so that the field wiring shield can be terminated. These analog shields shall be connected at the terminal to the DC ground net, which is connected to the negative terminal of the 24 VDC supply{38}, not earth ground.



2.2. Bill of Materials

The items in the following table shall be included. They are referred to through section 2 of this document, in the {}'s. Unless noted as "supplied by GE," the items from the Bill of Materials will have to be acquired by the vendor. Items with "or equivalent" noted can be substituted upon approval by GE.

| Test Control Box | | | | | | |
|------------------|---|---|-----------------|---------------|-------------------------|------------------------------|
| 1 | 1 | Ethernet isolated Din Switch | | B&B | EIR308 | |
| | | USB TO ISOLATED Serial 4 | | | USO9ML2- | |
| 2 | 1 | prt RS232 W/DB9M | | B&B | 4P | |
| | | | | | CSD30241 | |
| 3 | 1 | Main Test Enclosure | Hoffman | CSD302410 | CED | 2 |
| 4 | 1 | Mounting Plate | Hoffman | CP30P24 | CED | CP3024 |
| 5 | 1 | Mounting Kits | Hoffman | CMFK | CED | CMFK |
| 6 | 1 | USB A Bulkhead | DataPro | 1598-02C | DataPro | 1598-02C |
| | | HD15 Bulkhead VGA Panel- | | | | |
| 7 | 1 | Mount Ext CL2 PVC 2 ft | Data Pro | 1152-02C | DataPro | 1152-02C |
| 8 | 1 | VGA & USB Wall Plate | DataPro | 70302A | DataPro | 70302A |
| | | | | McMaster | | |
| 9 | 1 | Relay/Contactor | McMaster Carr | 70255K342 | Carr | 70255K342 or equivalent |
| 40 | 0 | Liquid Tight 1" Conduit Adapter | - | - | McMaster Carr | 75145K55 or equivalent |
| | | DAQ: Main Module (with MW100 Viewer Software), Math Function. | Yokogawa | MW100-E-1D | Measurement Instruments | MW100-E-1D Supplied by GE |
| 11 | 1 | DAQ: Base plate for one main and six I/O modules \$ | Yokogawa | MX150-6 | Measurement Instruments | MX150-6 Supplied by GE |
| 12 | 1 | DAQ: 10 ch 100 msec Form A contact relay | Yokogawa | MX125-MKC-M10 | Measurement Instruments | MX125-MKC-M10 Supplied by GE |
| 13 | 1 | DAQ:10 ch/100msec, DCV/TC/RTD/DI analog input module | Yokogawa | MX110-UNV-M10 | Measurement Instruments | MX110-UNV-M10 Supplied by GE |
| 14 | 1 | DAQ:10 ch/100msec, DCV/TC/RTD/DI analog input module | Yokogawa | MX110-UNV-M10 | Measurement Instruments | MX110-UNV-M10 Supplied by GE |
| 15 | 1 | DAQ:6 channels/100msec, 4-wire RTD, resistance, DCV and DI | Yokogawa | MX110-V4R-M06 | Measurement Instruments | MX110-V4R-M06 Supplied by GE |
| 16 | 1 | DAQ:8 ch 100msec 1 to 5V & 4 to 20mA output | Yokogawa | MX120-VAO-M08 | Measurement Instruments | MX120-VAO-M08 Supplied by GE |
| 17 | 1 | Thermal Data Acquisition | Agilent | 34972A | Newark | 55R0480 Supplied by GE |
| 18 | 1 | Thermocouple Input Cards | Agilent | 34902A | Newark | 83F4191 Supplied by GE |
| 19 | 3 | Resistor 250 ohm, 1% Tc = 50 ppm | Vishay | R60C2500BB14 | Newark | 83F1584 |
| 20 | 2 | 4 Position Modular Relay | Tyco/PB | 2IO4A | Newark | 81F4505 or equivalent |
| 21 | 1 | Board | Tyco/PB | OAC24A | Newark | 18M9254 or equivalent |
| 22 | 4 | 24 input 120 output relay | Honeywell | 11TS15-1 | Newark | 23F2113 or equivalent |
| 23 | 4 | Toggle switches | | | Newark | 15M3585 or equivalent |
| 24 | 1 | Cap for RJ45 pass through | Daniel Woodhead | ENSP1F5 | Newark | 15M0234 or equivalent |
| 25 | 1 | RJ45 pass through connector | Daniel Woodhead | 67-0300 | Newark | 15M3585 or equivalent |
| 26 | 1 | Cap for RJ45 pass through 2 Pole 32 A, 480 V circuit | | | Newark | 86K9999 or equivalent |
| 27 | 1 | breaker | | | Newark | 86K9999 or equivalent |

Any PC ok

19 May 2011

| | | | | | | | |
|-----|---|---|-------------------------------|---------------------|------------------|---------------------|-----------------------------|
| 28 | 1 | 1 Pole 40 A, 277 V circuit breaker | | | Newark | 32M7843 | or equivalent |
| 29 | 1 | 4PDT Relay for Manual Override | TYCO / POTTER & BRUM | KHAU-17A11N-120 | Newark | 87F1106 | or equivalent |
| 30 | 1 | Din rail mount relay socket | TYCO / POTTER & BRUM | 27E894 | Newark | 46F3589 | or equivalent |
| 31 | 1 | Power Strip | TRIPP LITE | 6SP | Newark | 87F2854 | or equivalent |
| 32 | 1 | LED 120 VAC overide indicator | | | Newark | 79M6920 | or equivalent |
| 33 | 1 | E-Stop Button | IDEC | AVW401-R | Newark | 74K3690 | or equivalent |
| 34 | 1 | Industrial Computer | Rave Computer | R-SFF-C2D-1 | | | Not available |
| 34A | 1 | | Superlogics | See PCs Spreadsheet | | | Substitute |
| 35 | 1 | Ventilation Fan | NMB-MAT | B50-A00 | Newark | 70K9511 | or equivalent |
| 36 | 2 | Finger Guard | NMB-MAT | 055015 | Newark | 93K7618 | or equivalent |
| 37 | 1 | Fan Power Chord | NMB-MAT | 432000 | Newark | 93K7643 | or equivalent |
| 38 | 1 | SPDT 120VAC 10 A relay | TYCO/PB | KUP-5A15-120 | Newark | 18M9148 | or equivalent |
| 39 | 1 | Relay Base | TYCO/PB | 27E893 | Newark | 46F3616 | or equivalent |
| 40 | 1 | 24 VDC 100W din power supply | 24 VDC 100 W Din Power Supply | | Newark | 73K6073 | |
| 41 | 1 | 120 VAC Plug | | | McMaster Carr | 7196K31 | or equivalent |
| 42 | 1 | 250 VAC 30 A Plug 3 terminal NEMA 90 degree | | | McMaster Carr | 8035K55 | or equivalent |
| 43 | 1 | Watt-Hour Sensor | | | Ohio Semitronics | W-119CX5 | Supplied by GE |
| 44 | 1 | RJ45 Breakout Box | EMERSON | 32-2038 | 32-2038 | Master Distributors | |
| 45 | 1 | USB-150: Full Speed USB Isolator | Keterex | USB-150 | Keterex | USB-150 | |
| 46 | 1 | ACER V173 DJB 17" Monitor | ACER | V173 DJB 17" CDW | | 2091793 | |
| 47 | 1 | USB Keyboard | Keytronic | KT400U2 | CDW | 1378635 | |
| 48 | 1 | IOGEAR 4PT USB 2.0 HUB | IOGEAR | Mfg#: IOR-GUH285 | CDW | 1571452 | |
| 49 | 1 | Optical Mouse | Kensington | Mfg#: KEN-K72356US | CDW | 1909960 | |
| 50 | 1 | FAN FILTER STARTECH FANFILTER12 RT | | | NewEgg | 11-993-011 | |
| 53 | 1 | Voltage Transducer | | | Ohio Semitronics | VTR-002D | salvaged from old equipment |
| 54 | 1 | Cat 5e Patch Chord 1' | | | Newark | 21M5869 | |
| 55 | 3 | Cat 5e Patch Chord 5' | | | Newark | 21M5656 | |
| 56 | 0 | Through Hole Cable Mounts | SPC | VRTH-05 | Newark | 81N2595 | Or Equiv. (Use as needed) |

Figure 2 Bill of Material for the TCB



2.3. External Connections

The output of the computer will consist of external connections to a VGA monitor output, and a USB connection for mouse and keyboard. These will be wired to ports on the outside of the TCB{6-8}. There shall also be a port from the Ethernet switch porting to the outside of the box for networking{25}.

The 120 VAC and 240 VAC supply lines shall have chord grips, attaching 3 feet of wire the their associated plugs {41,42}. The 240 VAC line shall be 3 conductor #8AWG wire.

2.3.1 Terminals for External Sensors

Terminal Blocks shall be clearly labeled, indicating the electrical node that is connected. Terminals shall be left explicitly intended for external sensors. A terminal for each of the entries shall be indicated, and clearly labeled. The external sensor block requirements are in the following chart:

| Terminal Block Wire Labels | | |
|----------------------------|--|---|
| Type | Intended Field Wire | Terminals |
| Pressure(x4) | Shielded 2x twisted pairs (24-18 AWG) | POWER |
| | | P_GND |
| | | SIG |
| | | S_GND |
| Heaters(x2) | Twisted Pair (16-22AWG) | Shield |
| | | + |
| | | - |
| | | |
| RTD_Temp(3) | Shielded 2x twisted pairs (24-18 AWG) | RTD_I |
| | | RTD_A |
| | | RTD_B |
| | | RTD_C |
| HEWH Power Output(1) | AWG8/10 x 3 | 240 L1 |
| | | 240 L2 |
| | | EGND |
| | | |
| Intellifaucet(1) | Shielded Multiconductor (AWG 24-18) | A:4-20+ |
| | | B:4-20- |
| | | C:Start |
| | | D:Stop |
| | | E:DGND |
| | | F:Ready |
| Solenoids(3) | Twisted Pairs (14-18 AWG) | G:Temp/Flow |
| | | 120 L |
| | | 120 N |
| | | EGND |
| DRM | Multiconductor (AWG 24-18) | DRM_0:PIN2 |
| | | DRM_REF:PIN6 |
| | | DRM_1:PIN3 |
| Tc_Temp(up to 59) | T Thermocouple Wire | No terminals for wiring. Attach directly to daq terminals |

Figure 3 Terminal Block Wiring



2.4. Power

The power to the box shall be 120 VAC for the test system, and 240 VAC for the HEWH. All of the current carrying wires for the 240VAC system will be AWG #8 to minimize measurement losses due to wire resistance. Both the 120 VAC and both legs of the 240VAC lines shall be protected by circuit breakers{27-28}. An emergency stop button{33} wiring through a relay{38,39} will be wired to disconnect the 120 VAC power for the system. One of the outputs of the MW100 will be used to trigger a contactor{9} that will allow 240 VAC power to flow to the water heater. This power going to the water heater will be monitored by an Ohio Semitronics Watt-Hour sensor{43}.

The power wiring should be segregated as much as possible from the sensor and control wiring.

3. Patch Panel Box (PPB)

The Test Control Box will be mounted on the outside of the chamber and have several conduit exits the will connect to the Patch Panel Box(PPB) mounted on the inside of the test chamber. The PPB will have the connectors to interface to the sensors employed in the test.

Each of the connector pins for the sensors will prewired to a termination block inside of the enclosure. These sensors include:

1. 48 Thermocouples (T)
2. 3 Pressure sensors (4 Wires)
3. 3 RTDs (5 Wires)
4. 1 Gas (6 wires)
5. 4 Serial Ports (6 wires)
6. 1 Spare (6 wires)

Use ICP CON



3.1 Pin Outs

The sensor wiring should all be done with shielded cable. The shield should be wired into one of the terminals. RTDs are wired into 5 terminal connections, Pressure Sensors are wired into 3 terminal connections, and Serial/Gas/Spare connections are wired into 6 pin connections.

The pinouts for the sensors should follow the following Chart:

| Pin | Pressure Sensor | RTD | Serial | Gas |
|-----|-----------------|--------|--------|--------|
| 1 | +V | I | RXD | +V |
| 2 | Sense | +A | TXD | +Sense |
| 3 | DC_GND | -B | GND | -Sense |
| 4 | Shield | C | Shield | DC_GND |
| 5 | NA | Shield | No Con | Shield |
| 6 | NA | NA | No Con | No Con |

Figure 4 Sensor Pin Out

Note that none of the shields are grounded in this box. The shields are to be grounded in the TCB. Terminals for the shields are to be provided in this box, and field wired back to the TCB.

The thermocouples will be left unconnected, to be attached during installation.

3.2 Heater Relay Inputs

External connections to the water heater to detect the state of the heating elements shall be made through turnlock connections {3,4} rated to 240 VAC. These connections shall then be wired to a solid state relay {15,16} that will be wired back to the TCB. The solid state relays shall bring the signal power down from 240 VAC to 24 VDC. Provisions for 3 of these inputs shall be made on the control box.




3.3 Bill of Material


| Patch Panel Box | | | | | | |
|-----------------|---|--|--------------------|----------------|------------------|---------------|
| 1 | 1 | Enclosure for sensor interface | | | CED | CSD241 668 |
| 2 | 1 | Mounting Plate | | | CED | CP2416 |
| 3 | 1 | Mounting Kits | | | CED | CMFK |
| 4 | 3 | Female Mini Turnlock for heater 240 VAC | McMaster Carr | 6755K21 | McMaster Carr | 6755K2 1 |
| 5 | 3 | Male Mini Turnlock Recept. 240 VAC | McMaster Carr | 6755K22 | McMaster Carr | 6755K2 2 |
| 6 | 3 | Thermocouple Jack Panel | Omega | SJP3-18-1 | Omega | SJP3- 18-1 |
| 7 | 3 | 5 PIN FEMALE PANEL MOUNT, SLIVER CONTACT, ZINC BODY | | | Newark | 87F660 3 |
| 7A | | | Multicomp/S PC | SPC21423 | Newark | 11M061 8 |
| 7B | | | Neutrik | 1 | Newark | 27B434 7 |
| 8 | 3 | 4 PIN FEMALE PANEL MOUNT, SLIVER CONTACT, ZINC BODY | | | Newark | 46F856 6 |
| 9 | 3 | 4 PIN MALE CONNECTOR, SLIVER CONTACT, ZINC BODY | | | Newark | 89F604 4 |
| 10 | 3 | 5 PIN MALE CONNECTOR, SLIVER CONTACT, ZINC BODY | | | Newark | 89F604 5 |
| 10 A | 3 | | Multicomp/S PC | SPC21436 | Newark | 11M063 1 |
| 11 | 4 | 6 PIN FEMALE PANEL MOUNT, SLIVER CONTACT, ZINC BODY | | | Newark | 87F660 5 |
| 12 | 4 | 6 PIN MALE CONNECTOR, SLIVER CONTACT, ZINC BODY | | | Newark | 89F604 6 |
| 13 | 1 | RJ45 pass through connector | Daniel Woodhead | ENSP1F5 | Newark | 15M023 4 |
| 14 | 1 | Cap for RJ45 pass through | Woodhead | 67-0300 | Newark | 15M358 5 |
| 15 | 2 | 240 VAC in, conf 367065, 24 VDC out relay | OPTO22 | IAC-24A | Newark | 18M910 4 |
| 15 A | 2 | | NTE | RIM- IAC24A | Newark | 02H694 5 |
| 16 | 1 | 4 Position Modular Relay Board | Tyco/PB | 2IO4A | Newark | 81F450 5 |
| 17 | 4 | Thermocouple connectors | Omega | CC-T-M | Omega | |

Figure 5 Bill of Material for the PPB


4. Further Considerations

1. All internal wiring shall be cable tied using a screw secured cable tie holders.
2. The computer will be specified per ongoing tests.







| | | |
|---------|--------------------|------------------|
| DWG.NO. | HEWH-CB1 | GENERAL ELECTRIC |
| TITLE: | HEWH - CONTROL BOX | REV. 0 |
| | | PAGE: 5 OF 5 |
| DATE: | 10/27/2010 | AUTH: JYC |




| | | |
|---------|--------------------|------------------|
| DWG.NO. | HEWH-CB1 | GENERAL ELECTRIC |
| TITLE: | HEWH - CONTROL BOX | REV. 2 |
| | | PAGE: 4 OF 5 |
| DATE: | 05/19/2011 | AUTH: JYC |




REFER TO HEWH-WIRING DIAGRAM FOR CABLE LAYOUT




| | | |
|---------|--------------------|------------------|
| DWG.NO. | HEWH-CB1 | GENERAL ELECTRIC |
| TITLE: | HEWH - CONTROL BOX | REV. 2 |
| | | PAGE: 3 OF 5 |
| DATE: | 05/19/2011 | AUTH: JYC |



| | | |
|---------|--------------------|------------------|
| DWG.NO. | HEWH-CB1 | GENERAL ELECTRIC |
| TITLE: | HEWH - CONTROL BOX | REV. 5 |
| DATE: | 05/19/2011 | PAGE: 2 OF 5 |
| | | AUTH: JYC |




| | | |
|---------|--------------------|------------------|
| DWG.NO. | HEWH-CB1 | GENERAL ELECTRIC |
| TITLE: | HEWH - CONTROL BOX | REV. 2 |
| DATE: | 10/27/2007 | PAGE: 1 OF 5 |
| | | AUTH: JYC |






| | | |
|---------|------------------------|------------------|
| DWG.NO. | HEWH-PP1 | GENERAL ELECTRIC |
| TITLE: | PATCH PANEL BOX WIRING | REV. 2 |
| DATE: | 12/15/2010 | PAGE: 1 OF 1 |
| | | AUTH: JYC |


| | | | | |
|----------|------------------|---|-----|---|
| DWG NO | | B | SHT | 1 |
| REVISION | | | | |
| REV | | - | | |
| | DATE: 10/11/2010 | 0 | | |



NOTES:
1A: 7310K14, PG16 (0.89" OD) CHORD GRIP 1X WIRE 5. HEWH WIRING REF. C8
1B,1C,1D: ONLY ON RLT UNITS, 7310K14, PG16 (0.89" OD) CHORD GRIP 1X WIRE 5. HEWH WIRING REF. C8
2A: 7310K12, PG9 (0.6 OD) CHORD GRIP 1X WIRE 3. HEWH WIRING REF. C16
2B: 7310K12, PG9 (0.6 OD) CHORD GRIP 1X WIRE 1. HEWH WIRING REF. C17.
3A: 7807K43, CHORD GRIP 1/2"NPT 0.84 OD, 6X WIRE 1. HEWH WIRING REF. C1-C6.
3B: 7310K12, CHORD GRIP 1X WIRE 1. HEWH WIRING REF. C7.
4: 5595K5, 1" MOUNTING HOLE. HEWH WIRING REF. C21.
5A: 7807K14, 3/14 NPT (1.05" OD) CHORD GRIP 4X WIRE 1. HEWH WIRING REF. C9-C12.
5B: 7310K12, PG9 (0.6 OD) CHORD GRIP 1X WIRE 5. HEWH WIRING REF. C13.
6: 7310K14, PG16 (0.89" OD) CHORD GRIP 1X WIRE 4. HEWH WIRING REF. C14, C15
7: 7310K14, PG16 (0.89" OD) CHORD GRIP 1X WIRE 2. HEWH WIRING REF. C20
H: LED INDICATION OF MANUAL OVERRIDE
I: 120 VAC 6" VENTILATION FAN
J: AIR VENTILATION INLET
K: MANUAL OVERRIDE SWITCHES




UNCONTROLLED IF PRINTED

| | | | | | | | | | |
|---|---|------------------|--|------------|--|---|--|--|--|
| ARTICLE OR MATERIAL MUST CONFORM TO ROHS PROCEDURE SI 900000 SECT 13 AND REACH PROCEDURE SI 900000 SECT 14 | UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES. DIMENSIONS IN [] ARE IN MM. TOLERANCES ON: 2 PL DECIMALS ± tolerance_2pl 3 PL DECIMALS ± tolerance_3pl ANGLES ± tolerance_angle ° FRACTIONS ± tolerance_fraction | APPROVED BY: | | DATE | | GENERAL ELECTRIC DEPT LOC LOUISVILLE, KY. | | | |
| | | DRAWN Jyc | | 10/28/2010 | | TITLE HEWH DAQ BOX | | | |
| | | CHECKED | | | | | | | |
| | | ENGRG. | | | | | | | |
| DO NOT SCALE THIS DRAWING | | ISSUED | | | | SIZE B DWG. NO. & FILENAME HEWH-CP-Holes1 DRW VER GEOM VER STATUS SHEET: 1 OF 1 | | | |
| THIRD ANGLE PROJECTION | | | | | | | | | |
|  | | | | | | | | | |
| | PART MUST CONFORM TO SI 900000 SECT.4 GEA TOXICITY PROCEDURE | | | | | B | | | |

| | | | |
|----------|-----------------|---|-------|
| DWG NO | | B | SHT 1 |
| REVISION | | | |
| REV | | - | |
| | DATE: 8/13/2010 | 0 | |

NOTES: CHORD GRIP pn'S FROM McMASTER CARR:
1: 1" OD, pn.55595K5 Chord Grip - FOR TcS.
2A: pn.7807K43, CHORD GRIP 1/2"NPT (0.84" OD), 6X WIRE 1. HEWH WIRING REF. C1-C6.
2B: pn.7310K12, PG9 (0.6" OD) CHORD GRIP 1X WIRE 1. HEWH WIRING REF. C7.
3A: pn.7807K14, 3/4 NPT (1.05" OD) CHORD GRIP 4X WIRE 1. HEWH WIRING REF. C9-C12.
3B: pn.7310K12, PG9 (0.6" OD) CHORD GRIP 1X WIRE 5. HEWH WIRING REF. C13.
B: TEMPERATURE JACK PANNELS
C: HEATER PICKUPS (TURNLOCK, 240VAC)
D: 4 PIN JACK
E: 5 PIN JACK
F: 6 PIN JACK


HOLES TO BE PUNCHED
IN EITHER THE RIGHT SIDE
OR THE LEFT SIDE, NOT
BOTH.



LEFT SIDE HOLE DRAWING





RIGHT SIDE HOLE DRAWING

UNCONTROLLED IF PRINTED

| | | | | | | |
|---|---|---------------------------------------|-------------|--|--------|---------------|
| ARTICLE OR MATERIAL MUST CONFORM TO ROHS PROCEDURE SI 900000 SECT 13 AND REACH PROCEDURE SI 900000 SECT 14 | UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES. DIMENSIONS IN [] ARE IN MM. TOLERANCES ON: 2 PL DECIMALS ± tolerance_2pl 3 PL DECIMALS ± tolerance_3pl ANGLES ± tolerance_angle ° FRACTIONS ± tolerance_fraction | APPROVED BY: | DATE | GENERAL  ELECTRIC DEPT LOC LOUISVILLE, KY. | | |
| | | DRAWN Jyc | 10/28/2010 | | | |
| DO NOT SCALE THIS DRAWING | PART MUST CONFORM TO SI 900000 SECT.4 GEA TOXICITY PROCEDURE | CHECKED | | TITLE HEWH PATCH PANNEL | | |
| | | ENGRG. | | | | |
| THIRD ANGLE PROJECTION | | ISSUED | | SIZE B | | |
|  | | | | | | |
| | | DWG. NO. & FILENAME HEWH-PP-Holes1 | | B | | |
| | | DRW VER | GEOM VER | --- | STATUS | SHEET: 1 OF 1 |





Frontplattenausschnitt (Rückseite)

Panel cut out (rear side)



| | | | | | | | | | |
|------|--------------------|----------|---------|--|--|-----------|------------|----------------|---------------|
| | | | | | Werkstoff: | Massstab: | | Datum | Name |
| | | | | | *Lieferant darf ohne Ruecksprache nicht geaendert werden | 3:1 | Gezeichnet | 07.02.96 | Dobler |
| | | | | | Zeichnung urheberrechtlich geschuetzt (DIN 34) (C) | | Geprueft | | |
| | | | | | | | Gesehen | | |
| | | | | | Benennung: (FP-1) | | | Ersetzt durch: | Blatt |
| | | | | | NC6FP-1 | | | Ersatz fuer: | von Blatt |
| A | Aktuelle Zeichnung | 27.03.98 | Alinjak | | NEUTRIK AG FL-9494 SCHAAN | | | Zeichn. Nr. | 3102 St 11 28 |
| Ind. | Aenderung | Datum | Name | | | | | | |




Frontplattenausschnitt (Rückseite)
Panel cut out (rear side)



| | | | | | | | | | |
|------|--------------------|----------|----------|--|------------|----------------|----------------|----------|---------------|
| | | | | | Werkstoff: | Massstab: | | Datum | Name |
| | | | | *Lieferant darf ohne Ruecksprache nicht geaendert werden | | 3:1 | Gezeichnet | 07.02.96 | Dobler |
| | | | | Zeichnung urheberrechtlich geschuetzt (DIN 34) (C) | | | Geprueft | | |
| | | | | Benennung: | (FP-1) | | Gesehen | | |
| | | | | | NC5FP-1 | | Ersetzt durch: | | Blatt |
| | | | | | | | Ersatz Fuer: | | von Blatt |
| A | Aktuelle Zeichnung | 27.03.98 | Alin,jak | | | | Zeichn. Nr. | | 3102 St 11 27 |
| Ind. | Aenderung | Datum | Name | | NEUTRIK AG | FL-9494 SCHAAN | | | |

Frontplattenausschnitt (Rückseite)

Panel cut out (rear side)



| | | | | | | | | | |
|------|--------------------|----------|---------|--|------------|----------------|----------------|---------------|-----------|
| | | | | | Werkstoff: | Massstab: | | Datum | Name |
| | | | | *Lieferant darf ohne Ruecksprache nicht geaendert werden | | 3:1 | Gezeichnet | 06.07.89 | Martinek |
| | | | | Zeichnung urheberrechtlich geschuetzt (DIN 34) (C) | | | Geprueft | | |
| | | | | Benennung: | (FP-1) | | Gesehen | | |
| | | | | | NC4FP-1 | | Ersetzt durch: | | Blatt |
| | | | | | | | Ersatz fuer: | | von Blatt |
| A | Aktuelle Zeichnung | 24.03.98 | Alinjak | | | | Zeichn. Nr. | 3102 St 11 07 | |
| Ind. | Aenderung | Datum | Name | | NEUTRIK AG | FL-9494 SCHAAN | | | |